


Right-handed
Push


EDGE 1




EDGE 2

Left-handed
Pull

EDGE 1




EDGE 2



- Watch our how-to videos at bladebarber.ca.
- Sharpen one blade edge at a time in the direction indicated by arrows.

Steps:

1. Place skate on its side with two pucks under the heel portion of the skate-blade-holder.
2. Hold the Blade Barber as shown with fingers on the **GB** logo.
3. **Keep the Blade Barber flat on the skate blade.** →
4. Slide the Blade Barber along the entire length of the skate blade and apply light pressure with your fingers. Take 4 passes.
5. Flip the skate over & take 4 passes to sharpen the other edge.
6. Tap the Blade Barber to remove shavings after each stroke.
7. Repeat steps 4 - 6 until the skate is sharp.

**Tips:**

- Color the hollow with a marker to see the sharpening process.
- There is a 5 minute learning curve. Don't rush the first sharpening.

Make the Blade Barber last:

- Use light pressure.
- Don't use the Blade Barber on heavily damaged skate blades.
- Use the Blade Barber when a good sharpener dulls, not to fix a bad sharpener.

